

AMERICAN BATH ENTERPRISES, INC.

26247 Research Rd., Hayward, CA 94545

PHONE: (888) 228-4925 FAX: (510) 785-6300

E-mail: info@americanbathind.com * Website: www.americanbathind.com

AMERIWALL CORNER SHELF UNIT INSTALLATION INSTRUCTIONS

YOUR NEW AMERIWALL CORNER SHELF UNIT (CS1610) IS DESIGNED TO BE INSTALLED AFTER THE AMERIWALL ENCLOSURE HAS BEEN INSTALLED.

IT IS IMPORTANT TO MAKE SURE THAT THE AREA COVERED BY THE CORNER SHELF UNIT IS CLEAN AND DRY IN ORDER FOR THE TAPE STRIPS AND CAULK TO ADHERE AND CURE.

- 1) **DO NOT REMOVE** THE TWO SELF ADHESIVE TAPE STRIPS FROM THE BACK SIDE OF THE CORNER SHELF UNIT.
- 2) **DO NOT REMOVE** THE TWO FOAM WEDGES FROM THE BACK SIDE OF THE CORNER SHELF UNIT.
- 3) LOCATE AND MARK AN AREA BETWEEN TWO ADJOINING ENCLOSURE WALLS FOR THE CORNER SHELF UNIT INSTALLATION.
- 4) IF REQUIRED, WRAP FINE SANDPAPER AROUND A SANDING BLOCK AND SAND ALL OUTER EDGES OF THE CORNER SHELF UNIT. THIS ENABLES A GAP FREE FIT WITH THE MOUNTING WALLS.
- 5) REMOVE PROTECTIVE BACKING FROM THE TWO SELF ADHESIVE TAPE STRIPS LOCATED ON THE BACK OF THE CORNER SHELF UNIT.
- 6) POSITION THE CORNER SHELF UNIT FIRMLY BETWEEN THE TWO MOUNTING WALLS, MAKING SURE THAT THE CORNER SHELF UNIT SEATS PROPERLY AND SQUARELY IN PLACE.
- 7) TO ASSURE PROPER SEATING AND THE PROPER ADHESION OF THE TAPE STRIPS, APPLY EVEN PRESSURE TO THE TWO VERTICAL CONCAVE SURFACES ON THE FRONT SIDE OF THE CORNER SHELF UNIT.
- 8) CAULK ALL OUTER EDGES OF THE CORNER SHELF UNIT WITH 100% SILICONE CAULK.
- 9) ALLOW 24 HOURS FOR THE SELF ADHESIVE TAPE STRIPS AND CAULK TO CURE PRIOR TO USING THE CORNER SHELF UNIT OR ENCLOSURE SYSTEM.